

SOLID TECH

Mounting instructions for the Cable Carrier

1. Turn the rear/back corner pillars 90 degrees as seen in below picture
2. Dismount the top lid from the Hybrid corner pillars and insert the Carrier in the corner pillar track
3. Remount the top lid in its original position
4. Remove the Cable Carrier top bar by turning the knobs
5. Carefully lay the HIFI cables on top of the lower Cable Carrier bar
6. Reinsert the top Cable Rack bar by turning the knobs

Attention!

The corner pillars need to be turned as shown in below picture.

